CONDITIONS

SMARTPHONES AND TABLETS GRADES

All devices will be data cleared, and free of enterprise (MDM) / customer (FMiP / user) locks. Each listing and the associated manifest will specify the operator (carrier) lock status. See the table below for examples of functional failures. Manifests detail device-level diagnostics.

Grade	Cosmetic Description	Functional Description	Battery Health
AA	Buyer's remorse / open box returns Like new condition • Minimal scratches and blemishes • External LDI not triggered	Fully Functional	≥ 80%
A+	Like New Condition • Minimal scratches	Fully Functional	≥ 70%
A	and blemishes External LDI not triggered	May have minor functional failure	Any
B+	Will allow more scratches and	Fully Functional	≥ 70%
В	blemishes than Grade A but no lens cracks on any surface External LDI not triggered	May have minor functional failure (display only)	Any
C+	More aggressive wear and tear • Will allow some cracks on certain	Fully Functional	≥ 70%
С	surface areas such as camera lens, rear lens but not on display cover lens External LDI not triggered	May have minor functional failure	Any
D+	Heavy cosmetic damage with cover lens cracks • Will have excessive damage on multiple surface areas and cracks on the cover lens • Missing small parts such as side keys, finger print sensor, speakers, flexes,	Fully Functional	≥ 70%
D	front camera, daughter boards, camera/flash lens and internal mechanical parts (Display, PCBA, Main/Rear Camera, Housing and Battery not considered small) Externally viewable LDI triggered but no corrosion	May have minor functional failure	Any
E (R2)	Any	Data not cleared, Batter Swollen, Bent	Any

EXAMPLES OF FUNCTIONAL FAILURES

Degree of Failure	Display Failure	Other Failure
Minor	 Missing pixels but no more than three Burn-in image on bar or menu areas Touch failure for product in which the touch panel is part of the cover lens All external display defects except cracks 	 Flash Proximity and light sensor Headset jack Vibrator Finger print sensor if not linked to the main board Battery Health Flip sensor
Major	 Missing pixels, more than three Burn-in image in center area Missing or discolor lines Touch failure for product in which the touch panel is part of the display Dark, white and discoloration spots Backlight brightness 	 Rear camera Front camera Speakers or microphones Side keys Dead battery Finger print sensor if linked to the main board Cannot defect SIM or SD card Does not charge Cannot connect to PC Wi-fi, Bluetooth, GPS